


HF-WiFi Config Tool User Manual

(Android Platform)
V1.0


- 1 After installed , there is an icon on the desktop of the OS as following picture.




- 2 The main page of the app is as following picture:




- 3 Click the menu button and the main menu will be popped up:**




- 4 Click the top right corner “flesh button” to search the device:**




- 5 Select one device to enter the device page, The default is try to make the module in command mode:




6 Click T-Tranission Mode to switch the module to through mode:




7 Input AT commands in input field(command mode) and click Send:




8 Click “Send File” to send command file in SD card:




9 Long Press the Echo Column and Clear the Echo Column context with the Clear Text button:



- 10 Reset and Reload Button will break the WiFi connection. When the WiFi connection is recovered, the software will try to make the module in command mode automatically.**



- 11 **Settings page can set the context of the broadcast, display the SSID and IP of AP connection. “Searching Code” and “UDP Port” should not be changed.**



Connect information of Hi-flying

Address: Room 511, 7# Building, No.365 Chuanhong Road, Pudong, Shanghai

postcode: 201202

Web: www.hi-flying.com

Online consultation: 400-189-3108

More information about Hi-flying products, please visit our web: <http://www.hi-flying.com/>

<The End>